



Installation Type 2b:

Volvo S40/V50 - MY 2004-2007 with Basic and High Performance sound system, without AUX input, with CDC




Installation Type 3a:


Vehicles with no existing CD changer

Set the dip switches as shown below.

Audi (MMI Basic Monochrome)



BMW E87, E90, E60/61, E63/E64, E70, E65 and Mini (Exept E60/61, E63/E64 Business)




BMW E60/61, E63/E64 Business (M-ASK, non-text capable)




Mercedes (Audio 20/50 and Comand)




Porsche (CDR 23/24 and PCM I/II/2.1)



Saab 9-3 (Rear CDC)




If you are connecting Gateway 500 to the back of the head unit, use this diagram:



Installation Type 3b:

If you are installing to a free fibre optic connector in the car (CDC preparation) use this method:



Text Configuration

Saab & Mercedes vehicles require final configuration of the Gateway as not all of the radios in these vehicles support text display. After Gateway 500 has been installed, toggle the mode selector switch six times (three times on/off) and a configuration menu will appear on the radio display. Select the configuration mode according to your head unit listed in the configuration table. To confirm the selection press and hold ►; to discard the selection press and hold ◀.

| Track # | Config | Mercedes Command | Saab Text |
|---------|---------|------------------|-----------|
| # 1 | NO TEXT | D | D |
| # 2 | Timeout | - | - |
| # 3 | Text | - | - |
| # 4 | +Cache | - | - |
| # 5 | +Paging | R | R |
| # 6 | +Select | - | R |


D: Default, R: Recommended

For detailed information visit:
<http://support.dension.com>



When servicing your vehicle

You must set the mode selector switch to service mode/bypass, CD Changer/position otherwise the service computer may detect an unknown device in the fibre optic system which can lead to errors reported.



GEN: Gateway enabler tool for Gateway 500 MOST BMW

User Manual

v1.0



xxxxxx

xxxxxxxx

1 Introduction

Introduction

The Dension Gateway Enabler tool (GEN tool) provides a quick and easy tool to help the installation of a respective Dension Gateway product for BMW vehicles with MOST system.

The proper functioning of the Gateway product requires that certain protocols in the car radio are enabled, which is not necessarily the case in all BMW vehicles. Enabling these protocols normally requires the car diagnostics tool of a BMW specialised workshop.

The GEN tool provides only the specific enabling/disabling diagnostics function without any other capabilities, which makes it a small and available device to help the installation/removal of the Gateway product.

Important note

When using the GEN tool for enabling, it gets linked to the specific Dension Gateway and the car it is installed to. Therefore:

- The Gateway has to be installed to the system before using the GEN tool.
- You cannot enable multiple cars with a single GEN tool.
- Keep the GEN tool with the owner of the Gateway as it may be needed in the future (e.g. when moving the Gateway to a different vehicle).

If the Dension gateway functions without using the GEN tool, please do not use the GEN tool.

The compatibility of the GEN tool may differ from the compatibility of the Gateway product. Please check the corresponding compatibility tables.

2 Compatibility

The GEN tool is compatible with the following vehicles:

| | |
|--------------------------------|---|
| 1 Series E81, E82, E87, E88 | NON i-Drive, Professional |
| | i-Drive, Business (M-ASK, 6.5", single slot) |
| | i-Drive, Professional (CCC, 8.8", dual slot) |
| 3 Series E90, E91, E92, E93 | NON i-Drive, Professional |
| | i-Drive, Business (M-ASK, 6.5", single slot) |
| | i-Drive, Professional (CCC, 8.8", dual slot) |
| 5 Series E60, E61 | iDrive 4, Professional (CIC, 8.8", dual slot) |
| | i-Drive, Business (M-ASK, 6.5", single slot) |
| | i-Drive, Professional (CCC, 8.8", dual slot) |
| 6 Series E63/E64 | i-Drive, Business (M-ASK, 6.5", single slot) |
| | i-Drive, Professional (CCC, 8.8", dual slot) |
| X5 E70 | i-Drive, Business (M-ASK, 6.5", single slot) |
| | i-Drive, Professional (CCC, 8.8", dual slot) |

3 Getting Started

First install the Gateway 500 according to the installation manual. It is recommended that the installation and using the GEN tool is performed by a professional installer.

Using the GEN Tool

Please make sure the Gateway 500 is in Gateway mode. Turn the ignition ON and connect the GEN tool to the OBD 2 diagnostic connector. The enabling procedure starts automatically and immediately and it takes approx. 20-30 seconds. During the enabling procedure the status signal LED on the GEN tool is flashing alternating Green and Red. When the enabling procedure is finished successfully the LED will turn to permanent green.

After the successful enabling the Audio system will restart. Do not remove the GEN tool before the restart of the audio system.

The GEN tool is capable of enabling almost all BMW vehicles with a MOST optical system, (see the compatibility table above). However, there may be very specific vehicle configurations and set-ups where the GEN tool is not operational and the enabling procedure cannot be completed. In such cases the LED on the GEN tool turns RED at the end of the enabling procedure.

If the LED is blinking RED, please check the GEN tool connection and make sure the ignition is turned ON.

If the problem still persists please contact your local supplier or open a support ticket at www.dension.com.

4 Servicing Your Vehicle

Vehicles with a MOST optical communication network have complex system management capabilities, and servicing may involve using a diagnostic computer. To avoid conflict with such diagnostics devices, Dension recommends disabling the previously activated functions.

How to disable

First set the mode selector switch on the Gateway Connector Port to service /bypass mode. Turn the ignition ON and connect the GEN tool to the OBD 2 diagnostic connector. The disabling procedure starts immediately and takes approx. 20-30 seconds. During the enabling procedure the status signal LED on the GEN tool is flashing alternating Green and Red. When the disabling procedure is finished the LED will turn to permanent green.

After the successful enabling the Audio system will restart. Do not remove the GEN tool before the restart of the audio system.

Association of the GEN Tool, the Gateway and the Vehicle

The GEN tool is delivered in a ready-to-enable state, which means that when plugging the GEN tool in to a vehicle with a gateway installed properly it will perform the enabling process automatically. At the same time it also associates to the specific vehicle and gateway.

If a GEN tool has already been associated to a vehicle and a Gateway product, it means it is in a ready-to-disable status. This means that when plugging a GEN tool in to the vehicle it is associated with it will perform the disabling process. After the successful disabling process the GEN tool will clear its associations and return to a ready-to-enable state.

If a GEN tool is in ready-to-disable status and plugged in to a different vehicle than the one it is associated to it does not perform any action and remains in ready-to-disable.

If the Gateway has been removed without disabling the vehicle, the associated GEN tool in ready-to-disable mode can still disable the vehicle and change to ready-to-enable mode.

5 Disclaimer and Warranty

Disclaimer

The GEN tool does not have all vehicle diagnostics and configuration functions that are available in other diagnostics tools. It is meant to help gateway installations only and to work on the big majority of the BMW vehicles with MOST systems where the respective Dension Gateway product is functional.

Despite all efforts and several tests Dension and its authorised distributors and retailers cannot guarantee for all vehicles that by using the GEN tool there is no need for enabling with a professional diagnostics tool.

The GEN tool can in many cases replace the enabling functions of a professional diagnostics tool, but in no way replaces the professional skills of a trained installer.

If your car's electrical system begins to behave erratically, please disconnect the GEN tool and the Gateway interface physically immediately and have it checked by your installer. Dension and its authorised distributors and retailers are not liable for any incidental consequential or indirect damages or loss and do not assume liability for any diagnostic fees.

Dension reserves the right to modify its products or specifications without prior notice.

Warranty

Dension devices carry a one-year limited warranty that protects you from defects in material and workmanship of products sold by Dension or its authorized distributors and retailers. Dension does not warrant any installation work or assume liability for any damage caused due to negligence, improper installation or operation. For warranty claims, proof of purchase is required.

Further Assistance


If you need further assistance in using your Dension Gateway, please contact your local supplier or visit www.dension.com and click on 'Support'.



1. Introduction

This user guide provides you with information on how to control and play your external audio device through a car entertainment system using a Dension Gateway (GW) interface.


It is assumed that the GW interface is already installed and correctly configured for your vehicle. For assistance with installation, please refer to the *Dension Gateway Installation and Configuration Guide*.



2. Car entertainment system requirements

This user guide does not provide information regarding operation with any specific car entertainment system. Please note the following:

1. Dension Gateway (GW) devices generally connect to the CD changer or auxiliary input on the car entertainment system. Please check www.dension.com for specific compatibility details.
2. If the vehicle has an existing CD changer it will be disabled by GW 100 and 300 unless an optional Dension CD Changer Retention module is also installed.
3. We use the conventions listed below to describe control of the GW from your car entertainment system. Please refer to your car entertainment system's owner's manual for specific details of its operation.



Next Track: **NEXT>**
Previous Track: **<PREV**
Fast Forward: **FF>**
Rewind: **<RW**

Note:
Some systems trigger <RW/FF> by a long press of <PREV/NEXT>

Repeat: **REP**
Random: **RND**
Scan: **SCN**


3. Text, browsing and song information

Even if your car entertainment system is unable to display text, you can control your external audio device with a Dension Gateway (GW).

If your car entertainment system has text capabilities, details of how to enable them are provided in the *Dension Gateway Installation & Configuration Guide*.

We refer to the different types of car entertainment system as follows:

1. **Browsing and playback:** full music browsing capabilities and song information displayed onscreen.
2. **Playback and text:** name of the artist, album or track that is playing. The number of characters will be defined by your display type.
3. **No text:** only CD and track numbers displayed, for example, CD6-08. Please refer to Section 6 for details on how CD numbers relate to operating modes.



4. External audio devices

The following external audio devices are supported:

| | |
|---|--|
| iPod® | Dock cable "(IPO4DC9)" Mini, 4G, 4G Photo, Nano, Nano 2G, Nano 3G, Nano 4G, 5G video, Classic, touch, touch 2G, iPhone 1G and iPhone 3G Active Cradle "(IP34CR9)" iPod 4G, 4G Photo, Nano 2G, Nano 3G, 5G video, Classic, iPhone 1G, touch 1G |
| USB | Flash memory or hard disk drives (USB mass storage) Music formats: MP3/WMA/Ogg/WAV File systems: FAT16/ FAT32 |
| Auxiliary Audio | GW 100 and 300 feature a 3.5mm stereo line input GW 500 features an RCA stereo line input |
| Bluetooth (requires optional Dension BTA series accessory) | A2DP/AVRCP profiles for audio playback HFP profile for handsfree telephony Refer to your car's user manual and the BTA 1500 user manual for telephone and telephone book operation |
| CD Changer (requires optional Dension CD retention kit) | Vehicle's existing original equipment if installed. This is a standard feature for GW 500 in certain vehicles |

5. Using the Dension Gateway

Before you start, please check that your iPod is up to date. You can get iPod firmware updates from www.apple.com/support/iPod

1. Connect your external audio device
2. Switch on your car entertainment system
3. Select external CD changer or auxiliary audio (note: In some vehicles (Opel and certain Fords), connection to the GW is made through the Aux port. It will therefore be necessary to select Aux rather than CDC. Playback starts from the last selected Dension Gateway audio source.)



6. Operating modes

For iPod and USB device control, the following operating modes can be used by selecting the corresponding CD. Use <PREV/NEXT> to select and play the playlist, artist, album or track. Dension GW returns to CD5 after 30 seconds of inactivity in any other CD mode.

Text-capable display Non-text display

| | |
|----------------------|-----------------|
| 15:31 ChillOut | 15:31 Track4 |
| CD1 2.45 65 miles | 65 miles |

| | |
|------------------------|-----------------|
| 15:31 Akon | 15:31 Track4 |
| ChrisBrown 65 miles | 65 miles |

| | |
|--------------------------|-----------------|
| 15:31 Graduation | 15:31 Track4 |
| InMyOwnWords 65 miles | 65 miles |

| | |
|------------------------------|----------------------|
| 15:31 PlayAll | 15:31 Track4 |
| Repeat Random 65 miles | CD4 2.45 65 miles |

| | |
|-------------------------------------|----------------------|
| 15:31 BecauseOfYou | 15:31 Track4 |
| BeautifulLies Caught 65 miles | CD5 2.45 65 miles |

| | |
|------------------------------|----------------------|
| 15:31 AuxGW | 15:31 Track3 |
| iPodUI iPodGW 65 miles | CD5 2.45 65 miles |

if your car's system only supports five CDs, CD4 functions are removed. CD5 and CD6 functions move to CD4 and CD5.



7. Source table

Note: if your vehicle does **not** have text capability, select CD6 on the changer to access the following source modes.

| Track | Source | Description |
|-------|-----------------|--|
| 1 | Auxiliary Input | Plays audio from the device connected to the Dension Gateway (GW) auxiliary input |
| 2 | iPod UI | Enables you to use the iPod click wheel for audio selection (recommend for vehicles without Browsing and Playback capabilities) |
| 3 | ipod GW | Audio selection for the iPod is via the car entertainment system controls (recommended for vehicles with Browsing and Playback capabilities) |
| 4 | USB | Plays music from the USB device connected to the Dension Gateway (not GW100) |
| 5 | BT Audio | Streams music from the Bluetooth audio device paired with the GW |
| 6 | BT Phone | Provides handsfree telephone functions from the Bluetooth phone paired with the GW |
| 7 | | <i>Reserved for future use</i> |
| 8 | | <i>Reserved for future use</i> |
| 9 | CDC | GW100/300: Plays CDs from the vehicle's original CD changer. To return to GW operation press either REW , RPT or SCN twice. Some vehicles may require power to the entertainment system to be turned off and then back on again (reboot) after the double-press. Note: at least one CD must be loaded into the magazine otherwise it is not possible to return to Gateway Dension operation. GW 500: Vehicles which support multiple CD changers will list the Gateway operating modes in sequence with the CDs loaded in the vehicle's CD changer. To switch between GW 500 and CD changer on vehicles which do not support multiple CD changers, use the bypass switch on the GW 500 auxiliary input box (some vehicles require a shutdown and cold start for this mode change). |

8. More information

CD4 functions (continued from Section 6)

PlayAll

Start playback of all content on your device.

For USB mass storage devices:

Build database

When using USB content, the Dension Gateway (GW) generates a database for easy Folder/Artist/Album navigation. Normally this will only take a few seconds, but for large capacity drives like a 100GB Hard Drive (HD), it can take up to one hour or more.

If the GW finds tracks have been deleted from the HD or USB content, it will automatically regenerate the database. However, if tracks have been added, this will have to be done manually. Dension are working on software to assist with manual database regeneration (Gateway Utility). Please check www.dension.com for availability.

Set bookmark

Bookmark a position within a track, album or playlist to restart playback from.

Resume bookmark (USB)

Playback returns to the position set by the bookmark.

Help and support

If you need further assistance in using the Dension Gateway, please contact your local supplier or visit www.dension.com and click on 'support'.

Disclaimer

If your car's electrical system begins to behave erratically, please disconnect your Dension Gateway interface immediately and have it checked by your installer. Dension and its authorised distributors and retailers are not liable for any incidental consequential or indirect damages and do not assume liability for any diagnostic fees.

The use of handheld devices while driving may be subject to government legislation. Please ensure that your use of the Dension Gateway complies with applicable traffic laws. Dension does not assume liability for any events resulting from the illegal or irresponsible use of handheld devices while driving.

Warranty

The Dension Gateway interface carries a one-year limited warranty that protects you from defects in material and workmanship of products sold by Dension or its authorised distributors and retailers. Dension does not warrant any installation work or assume liability for any damage caused due to negligence, improper installation or operation. For warranty claims, proof of purchase is required.

DENSION
Audio Systems
Gateway

100 / 300 / 500



User Guide